


**Garagescape**Make room for what you love.

RETAIL DIVISION

**CONSUMER DIVISION** 

## 96"H x 48"W Vertical Slatwall Panel Handling Instructions



- 1. Vertical panels should be flat on the ground.
- 2. With one person on each end of 96" side, lift the panel up horizontally, and carry to desired location.




CAUTION! Do not lift 48" ends upward.

3. Before tilting upright into the vertical position, place a corner onto a rag or towel to prevent damage.



CAUTION! A minimum of two people are needed to support the top half of the panel to prevent panel from tilting forward. Tilting will cause the panel to break into two pieces.

For more information, call 800.548.7528 to speak with one of our expert Project Managers or visit www.windmillslatwall.com or www.garageescape.com.



## Recommended Accessories

- Leather gloves
- Safety glasses
- Rag or towel



800.548.7528 | InfoRequest@windmillslatwall.com | www.windmillslatwall.com | Wind Mill Slatwall Products, a division of Amerhart | 200 Balsam Road | Sheboygan Falls, WI 53085