

NCHOR[™] CORE SLATWALL 50%[®] Stronger

Brick Series

The Brick Series includes Brickyard[™] and Brickwall[™] providing rich texture and color options to create an authentic brick appearance. Custom colors create an eye catching experience.

Brickyard[™] offers a two piece construction with functional grooves every 5 ¼ inch. Functional grooves are machined every other grout line producing a textured brick appearance. It not only looks great, it has all the functionality of slatwall. We also offer the option of custom painted inserts for Brickyard[™].

Brickwall™ is an alternative to Brickyard[™] where custom machining and painting create a modern, like brick pattern.

Options include custom factory finishing or shipped ready to paint.

For Information and sample request please visit www.windmillslatwall.com or call 800.548.7528 to consult with our expert Project Managers for all custom projects.



Brickyard™

- Nominally sized 95 ½" H x 47 ½ " W Slatwall panel.
- Grooves are cut every other grout line approximately 5 1/4" on center.
- Customized finishes available.
- Custom Painted Inserts.

Brickwall™

- 96" x 48" panel can be custom cut to specification.
- Can be made from a full range of core and surface finishes.
- Grooves can be painted to further simulate the look of actual brick.

800.548.7528 | InfoRequest@windmillslatwall.com | www.windmillslatwall.com Wind Mill Slatwall Products, a division of Amerhart | 200 Balsam Road | Sheboygan Falls, WI 53085




Panel Installation Instructions

- 1. Determine location where panels will be installed. Use a level to draw a straight line at desired height.
- 2. When installing over drywall use a stud finder to mark the center of each stud on the pre drawn level line.
- 3. Use correct length screws to attach panel to the wall, drilling through the grooves (see Illustration A below). Due to the uniqueness of each installation, **fastening screws are not included.**
- 4. If cutting is required, cut wall panels with a power saw. The saw blade should enter the finished side of the wall panels (back side of board is facing up).

► Special Note

1. Clean with damp soft cloth limiting water and harsh chemicals.



TIP: For a single

a level 2'H x 4'L assist

Panel 7

12'H x 4'W

Assist Board

person installation, mount

board to rest the panel on.



Accessories provide the ability to create personalize organization providing a simple way to arrange and rearrange products. Use shelves, baskets, and various hooks to meet your organizational needs.

Necessary Tools

- Safety goggles
- Tape measure
- Stud finder
- Level
- Standard drywall screws
- Drill (screw gun)

Safety First

Use all tools according to the manufacturer's recommendations.

Do's and Dont's

- DO distribute weight equally on the panels.
- DO use tools per manufacturer's recommendations.
- DON'T climb, hang, or step on accessories.
- DON'T overload accessories with additional weight.
- DON'T drop heavy items on accssories.



800.548.7528 | InfoRequest@windmillslatwall.com | www.windmillslatwall.com Wind Mill Slatwall Products, a division of Amerhart | 200 Balsam Road | Sheboygan Falls, WI 53085

Illustration A → Install standard drywall screws through the backof the grooves (fastening screws are not included)