

NCHOR<sup>™</sup>CORE SLATWALL 50%<sup>°</sup>Stronger

# DASHwall<sup>™</sup> Series

Anchor<sup>™</sup> Core is **50% stronger** than slatwall made with medium density fiberboard (MDF) core.

#### Wind Mill Slatwall Products is the **exclusive** manufacturer of Anchor<sup>™</sup> Core retail display panels.

For an eye catching effect, DASHwall<sup>™</sup> is produced with a variety of inline or staggered grooves. This stylish series provides ample accessory configurations to meet the needs of specific displays.

For Information and sample request please visit www.windmillslatwall.com or call 800.548.7528 to speak with a Project Manager.

Consult our expert Project Managers for all custom projects.



## DASHwall<sup>™</sup> Series

- Made with Anchor<sup>™</sup> Core
- Customized finishes
- A variety of configurations

800.548.7528 | InfoRequest@windmillslatwall.com | www.windmillslatwall.com Wind Mill Slatwall Products, a division of Amerhart | 200 Balsam Road | Sheboygan Falls, WI 53085






#### Panel Installation Instructions

- 1. Determine location where panels will be installed. Use a level to draw a straight line at desired height.
- 2. When installing over drywall use a stud finder to mark the center of each stud on the pre drawn level line.
- 3. Use correct length screws to attach panel to the wall, drilling through the grooves (see Illustration A below). Due to the uniqueness of each installation, **fastening screws are not included.**
- 4. If cutting is required, cut wall panels with a power saw. The saw blade should enter the finished side of the wall panels (back side of board is facing up).

## ► Special Note

- DASHwall<sup>™</sup> is intended for medium and light weight use. Do not overload DASHwall<sup>™</sup> grooves with weight since there is less than 6" of material between grooves.
- 2. Clean with damp soft cloth limiting water and harsh chemicals.



TIP: For a single person installation, mount a level 2'H x 4'L assist board to rest the panel on.



Assist Board

#### Accessories

Accessories provide the ability to create personalize organization providing a simple way to arrange and rearrange products. Use shelves, baskets, and various hooks to meet your organizational needs.

#### **Necessary Tools**

- Safety goggles
- Tape measure
- Stud finder
- Level
- Standard drywall screws
- Drill (screw gun)

# Safety First

Use all tools according to the manufacturer's recommendations.

# Do's and Dont's

- DO distribute weight equally on the panels.
- DO use tools per manufacturer's recommendations.
- DON'T climb, hang, or step on accessories.
- DON'T overload accessories with additional weight.
- DON'T drop heavy items on accssories.



800.548.7528 | InfoRequest@windmillslatwall.com | www.windmillslatwall.com Wind Mill Slatwall Products, a division of Amerhart | 200 Balsam Road | Sheboygan Falls, WI 53085